


175-inch model shown



SR1A is a rugged, low-cost, high performance string pot built for wet environments and outdoor applications. Originally designed for off-road construction equipment, the SR1A is the perfect low-cost solution for OEM and stocking distributors.


Available in 62-inch, 125-inch and 175-inch stroke ranges, the SR1A is constructed of a rugged polycarbonate enclosure designed to withstand impact from harsh environments and rugged conditions. Each sensor ships with a handy mounting bracket to make just about any installation very simple. Every SR1A ships with a field installable mating connector and optional cordsets are available.

SR1A Cable Actuated Sensor Industrial • Voltage Divider Output


Precision Potentiometric (Voltage Divider) Output 0–62, 0–125 and 0-175 inch Range Options Designed for Outdoor & IP67 environments In Stock for Quick Delivery!

Specifications

Measurement Range, SR1A-62 0-62 in. (0-1575 mm) Measurement Range, SR1A-125 0-125 in. (0-3175 mm) Measurement Range, SR1A-175 0-175 in. (0-4445 mm) Accuracy ± 0.5% FS. Sensor plastic-hybrid precision potentiometer **Input Resistance** 10K ohms **Maximum Input Voltage** 30 volts AC/DC Resolution essentially infinite Repeatability ± 0.1% FS. .034-inch dia. nylon-coated stainless **Measuring Cable Maximum Velocity** 80 inches (2 meters) per second **Maximum Acceleration** 10 g (retraction) **Measuring Cable Tension** 23 oz. (6,4 N) ±30% Cycle Life 250,000 (potentiometer) Enclosure Polycarbonate **Electrical Connection** M12 Connector (mating plug included) **Environmental Suitability** NEMA 6. IP67 **Operating Temperature** -40° to 185° F (-40° to 85° C) Weight 2.5 lbs. (1.3 Kg)



Electrical Connection



Changing the Cable Exit

Changing Measuring Cable Exit

To change the direction of the measuring cable, remove the 4 mounting bracket screws and rotate bracket to one of four available positions. See figures 1 - 4 on the following pages for mounting dimensions.

Changing Electrical Connector Direction

To change the position of the electrical connector, remove the 4 rear cover screws and carefully separate rear cover from the sensor body.

Rotate the rear cover to desired position being careful to not tangle the wiring harness that runs to the connector.




Fig. 1 - Outline Drawing (as shipped)




Fig. 2 - "Up" Cable Exit Direction




Fig. 3 - "Down" Cable Exit Direction





Fig. 4 - "Rear" Cable Exit Direction



units are in inches [mm] tolerances are \pm .04 [1,0] unless otherwise noted

Ordering Information



Order No. SR1A-62

62-inch stroke range, voltage divider output, 4-pin M12 mating plug & mounting bracket included.





4-pin M12 x 13 ft (4 m)

22 AWG (.34mm²)



order No. SR1A-125

125-inch stroke range,voltage divider output,4-pin M12 mating plug & mounting bracket included.





175-inch stroke range, voltage divider output, 4-pin M12 mating plug & mounting bracket included.

OPTIONAL CORDSET

for short-run connections, a convenient optional 13-ft. cordset with a 4-pin M12 connector is available.